

TECH-NOTE



1100 Norman Street, Suite 200
Lachine, QC Canada H8S 1A6
Tel.: (800) 426-5207
(514) 637-5572
Fax: (514) 637-3985
E-mail: wildfire@tycoint.com
www.wildfire-equipment.com

NUMBER 14 DECEMBER 14, 2009

FIREQUICK PRODUCT LINE UPDATE



NEW LAUNCH-ONLY STUBBY

The Dual Stubby (launch or throw) has been re-configured to be a Launch-Only Stubby as of June 2009. This version exhibits an increase in performance alongside a reduction in cost. Without the bulk of the dual igniter there is more fire-power packed into the compact flare. The launch-only stubby is extremely effective in light to medium fuels including damp fuel conditions with a 10 to 15 second delay. The energetic flare sprays 4000°F material ~6 feet.

Features

- It is mechanically launched, remote ignition flare
- Use Launcher II (Dual Launcher) only
- Load cap end into barrel
- #6 or #7 cartridge recommended
- Launch distance ~300'
- Allow minimum 40' safety zone
- Only use in a Firequick Launcher



Tips:

- + If the cap is removed DO NOT fire from the Launcher
- + ONLY launch the Stubby from a Firequick Launcher

TO ORDER PLEASE REFERENCE PART NUMBER:
QUO-FQ-15-STB-LO

FIREQUICK PRODUCT LINE UPDATE

NEW "CHUBBIE" FLARE

The new Chubbie Flare is hand-throw only flare (available since June 2009). Due to the weight and compact nature, the Chubbie is an excellent option for areas with heavier fuels or where launching is not the best option.

Features

Compact and extremely rugged at only 2.5" in diameter and 2" high

Light-weight, easy to pack, easy to throw

High performance ignition in light to medium-heavy fuels

Approximate 15 second delay

Energetic flare sprays 10-12 feet

Allow 40' minimum safety zone

Tips:

- + Control cord after ignition & while throwing
- + NEVER remove caps and extend cords before ready for use
- + Do NOT transport or store Chubbie flares without cord protection



Chubbie flare

**TO ORDER PLEASE REFERENCE PART NUMBER:
QUO-FQ-15-STB-LO**

Easy to use:

1. Remove cap
2. Extend the grey igniter cord fully
3. Eliminate cross-over (recommend holding the cord as illustrated)
4. Select target zone
5. Place flare and light OR light flare and throw (users should immediately throw the flare after lighting the cord. There is sufficient time delay in the cord length to use this method safely).
6. Allow 40' safety zone



1100, rue Norman, bureau 200
Lachine, QC Canada H8S 1A6
Tél.: (800) 426-5207
(514) 637-5572
Télec.: (514) 637-3985
Courriel: wildfire@tycoint.com
www.wildfire-equipment.com